

Interfacing the KXP94 or KXR94 Tri-Axis Accelerometer with the Texas Instruments MSP430F149 Microprocessor to Measure Tilt and Other Motions

This application report describes how to integrate the Kionix KXP94 or the KXR94 tri-axis accelerometer with the MSP430F149 to capture and utilize the motion sensing capabilities of the accelerometer. Example code is provided for capturing and using tilt sensing, vibration sensing and acceleration. Source code is provided for the MSP430F149 as well as source code for the demonstration software drivers and applications.

Introduction

Kionix linear accelerometers function on the principle of differential capacitance. Acceleration causes displacement of a silicon structure resulting in a change in capacitance. A signal-conditioning CMOS technology ASIC detects and transforms changes in capacitance into an analog output voltage which is proportional to acceleration. The output voltage is sent to the MSP430F149 ADC for conversion to a digital signal. This signal can then be sent to a serial port, an IR chip, a flash NAND for storage, a USB port, through SPI or $\rm I^2C$ to another processor, etc. A serial port is used for the following examples.

In the examples that follow the MSP430F149 waits for user input, via the serial port, to retrieve the requested data from the accelerometer. The analog output voltages generated by the KXP94 or KXR94 are sent to the MSP430F149 ADC for conversion to a digital signal. The MSP430F149 moves the digital data to a buffer and then sends the data, via the USART, to the serial port. The data, now in numerical format, is received by the software driver (see example code), converted to actual g-force and then sent to the calling program (see example code).

Software Implementation, Example Software Drivers and Demos

MSP430F149 Code

MSP-FET430P140 Demo - ADC12, Sequence of Conversions (non-repeated)

Description: This program will show how to convert a non-repeated sequence of channels.

This example shows how to perform A/D conversions on a sequence of channels. A single sequence of conversions is performed - one conversion each on channels A0, A1, A2, and A3. Each conversion uses AVcc and AVss for the references. The conversion results are stored in ADC12MEM0, ADC12MEM1, ADC12MEM2, and ADC12MEM3 respectively and are moved to R5, R6, R7, and R8 respectively after the sequence is complete. Test by applying voltages to pins A0, A1, A2, and A3, then setting and running to a break point at "jmp Mainloop." To view the conversion results, open a register window in C-Spy and view the contents of R5, R6, R7, and R8.

Note that a sequence has no restrictions on which channels are converted. For example, a valid sequence could be A0, A3, A2, A4, A2, A1, A0, and A7.

```
See the MSP430x1xx User's Guide for instructions on using the ADC12.
  *Note* This example only functions on MSP production silicon, not PMS
  pre-production silicon. Production silicon will be noted on the chip as
  "M430F149" whereas pre-production silicon will be marked "P430F149."
         MSP430F149
              A0 I<---- Vin0
              A1 |<---- Vin1
              A2 I<---- Vin2
              A3 I<---- Vin3
  M.Mitchell
  Texas Instruments, Inc
  January 2004
#include
             "msp430x14x.h" // Standard Equations
        ORG
main
                01100h
                                 ; Program Start
RESET
                 #0A00h,SP
          mov
                                    ; Initialize stackpointer
                 #WDTPW+WDTHOLD,&WDTCTL ; Stop watchdog
      bis.b #BIT0+BIT1+BIT2+BIT3,&P6SEL; Enable A/D channel inputs
SetupADC12 mov
                   #ADC12ON+MSC+SHT0_2,&ADC12CTL0; Turn on ADC12, set
MSC
             #SHP+CONSEQ_1,&ADC12CTL1; Use samp. timer, single sequence
      mov
      bis.b #INCH 0,&ADC12MCTL0
                                    ; AVcc=ref+, channel=A0
      bis.b #INCH 1,&ADC12MCTL1
                                      ; AVcc=ref+, channel=A1
      bis.b #INCH 2,&ADC12MCTL2 ; AVcc=ref+, channel=A2
      bis.b #INCH 3+EOS,&ADC12MCTL3; AVcc=ref+, channel=A3, end seq.
             #BIT3.&ADC12IE
                                  ; Enable ADC12IFG.0 for ADC12MEM0
      mov
      bis
            #ENC,&ADC12CTL0
                                   ; Enable conversions
      eint
                          ; Enable interrupts
Mainloop bis
               #ADC12SC,&ADC12CTL0 ; Start conversions
            #CPUOFF,SR
      bis
                                ; Wait in LPM0 for seq to complete
                          ; Only Required for CSPY
      nop
                              ; SET BREAKPOINT HERE
      jmp
            Mainloop
ADC12ISR ; Interrupt Service Routine for ADC12
      bic #CPUOFF,0(SP)
                                    ; Move A0 result
      mov
             &ADC12MEM0,R5
```

; Move A1 result

; Move A2 result

; Move A3 result, IFG is reset



&ADC12MEM1,R6

&ADC12MEM2,R7

&ADC12MEM3,R8

mov

mov

mov reti

```
Interrupt Vectors

ORG 0FFFEh ; MSP430 RESET Vector
DW RESET ;
ORG 0FFEEh ; ADC12 Interrupt Vector
DW ADC12ISR ;
END
```

Software Driver

Example Pseudo-code For Retrieving An Acceleration Reading


```
SerialPort.send("x") // For this example, the requested axis will be X Reading = SerialPort.recieve(2 bytes) // Value is sent as a 2-byte integer Voltage = Reading/4096 // This ratio is defined by the A/D converter Acceleration = (Voltage*1000)/Sensitivity // Sensitivity is in mv/g Acceleration -= AdjustmentX // Center reading based on earlier calibration return Acceleration // Acceleration is returned in q's
```

Hardware Implementation

Kionix has designed and built a small development board that interfaces a KXP94 or KXR94 with the Texas Instruments MSP430F149. The KXP94-DEV-V1 (KXP94-2050 Development Board) or the KXR94-DEV-V1 (KXR94-2050 Development Board) allows users to rapidly develop motion based applications using the processing capabilities of the MSP430F149. boards and evaluation boards are available at

http://www.kionix.com/sensors/evaluation-kits.html. The schematic for the KX_94-DEV-V1 is shown on the following page.







Software Demos for the Development Board

A variety of small applications which work with the development board and will run on a Windows-based PC is available at http://www.kionix.com/sensors/downloads.html. Download the latest version of the file named Kionix Demonstration Software. An executable installer will install the demonstration software on your computer.

For more information about how to use the software with the development board, please refer to the User's Manual for the KX_94-DEV-V1 Development Board available at http://www.kionix.com/sensors/evaluation-kits.html.

Theory of Operation

Kionix MEMS linear tri-axis accelerometers function on the principle of differential capacitance. Acceleration causes displacement of a silicon structure resulting in a change in capacitance. A signal-conditioning CMOS technology ASIC detects and transforms changes in capacitance into an analog output voltage which is proportional to acceleration. These outputs can then be sent to a micro-controller for integration into various applications. Kionix technology provides for X, Y and Z-axis sensing on a single, silicon chip. One accelerometer can be used to enable a variety of simultaneous features including, but not limited to:

- Drop force modeling for warranty management
- Hard disk drive shock protection
- Tilt screen navigation
- Theft, man-down, accident alarm
- Image stability, screen orientation
- Computer pointer
- Navigation, mapping
- Game playing

For product summaries, specifications, and schematics, please refer to the Kionix accelerometer product sheets at

http://www.kionix.com/sensors/accelerometer-products.html.

